

BlackBerry® & iBox Devices

BlackBerry Requirements:



- phones or tablets with OS 5 or newer
- a cellular data plan with Internet service
- a current Supra® eKEY® app downloaded on the device from the BlackBerry App World®

Some BlackBerry Device Examples:

8800 series
 Bold™
 Curve™
 Pearl™

Storm™
 Style™
 Torch™
 Tour™

NOTE: The BlackBerry 10 is not supported at this time.

iBox BT LE	iBox BT	Classic iBox
 <p data-bbox="142 972 526 1077">No additional hardware is needed to open the iBox BT LE</p> 	 <p data-bbox="581 972 1040 1045">No additional hardware is needed to open the iBox BT</p> 	 <p data-bbox="1084 972 1490 1077">The BlackBerry needs a Supra eKEY Fob to open the iBox</p>  <p data-bbox="1252 1224 1308 1255">plus</p>  <p data-bbox="1393 1293 1433 1314">Fob</p>
<p>Contact Support at 1-877-699-6787 if you have questions about a specific BlackBerry product.</p>		

Compatible eKEY Devices List
[Click Here](#)

New Zealand eKEY Customers
[Click Here](#)

www.supraekey.com

