

# eKEY® App Compatible Phones and Tablets

## iBox BT LE Keyboxes

### Android™

#### Requirements:

- Phones or tablets with OS 2.1 or newer
- A cellular data plan
- The current eKEY application downloaded to the Android phone or tablet

#### Some Example Devices:

<b>Google</b>	Nexus™ 7, Nexus One, Nexus S
<b>HTC™</b>	Aria™, Desire, Eris, EVO™ 4G & 3D, Hero™, Incredible 2, Incredible, Sense, Thunderbolt™, Touch 2, and Wildfire™
<b>LG®</b>	Enlighten™, Intuition™, Optimus™, Revolution™, Thrill™, and Vortex™
<b>Motorola™</b>	Atrix 2, Bionic, Droid 2, Droid X, Razr, Razr M
<b>Samsung®</b>	Charge, Epic™, Galaxy S™7, S6, S5, S4, S3, S2, & S, Galaxy Note™ 4, 3, & 2, and Moment

### Apple®

#### Requirements:

- Phones or tablets with iOS 6 or newer
- A cellular data plan
- The current eKEY application downloaded to the Apple phone or tablet

Supra eKEY Fob or Adapter is not needed for iBox BTLE (Bluetooth 4.0) if the Apple products are:

- iPhone models 4s or newer
- Retina iPad model or newer
- iPad Mini

#### Use a Supra eKEY Fob:

For iBox BT LE devices with older Apple products or when opening an iBox BT (Bluetooth 2.0) device.

- iPhone models 4 and older
- iPad 2 models and older
- iBox BT device

#### Some Example Devices:

Open an iBox BT LE without using a Supra Fob:

<b>iPhone®</b>	7 Plus, 7, 6s Plus, 6s, 6 Plus, 6, 5s, 5c, 5, and 4s
<b>iPad®</b>	iPad Mini, iPad Pro, 4 <sup>th</sup> Generation and 3 <sup>rd</sup> Gen.

### BlackBerry®

#### Requirements:

- Phones or tablets with OS 5 or newer, except BlackBerry 10
- A cellular data plan
- The current eKEY application downloaded to the BlackBerry phone



Supra eKEY Fob

#### Some Example Devices:

<b>BlackBerry</b>	8800 series Bold™ Touch Curve™ Pearl™/Pearl Flip Storm™ Torch™ Tour™
-------------------	--

Contact Support at 1-877-699-6787 if you have a question about a specific phone or tablet.

**Compatible eKEY App Devices**  
List  
[Click Here](#)

[www.supraekey.com](http://www.supraekey.com)

