

eKEY® App Compatible Phones and Tablets

iBox BT LE Keyboxes

Android™

Requirements:

- Phones or tablets with OS 2.1 or newer
- A cellular data plan
- The current eKEY application downloaded to the Android phone or tablet

Some Example Devices:

Google	Nexus™ 7, Nexus One, Nexus S
HTC™	Aria™, Desire, Eris, EVO™ 4G & 3D, Hero™, Incredible 2, Incredible, Sense, Thunderbolt™, Touch 2, and Wildfire™
LG®	Enlighten™, Intuition™, Optimus™, Revolution™, Thrill™, and Vortex™
Motorola™	Atrix 2, Bionic, Droid 2, Droid X, Razr, Razr M
Samsung®	Charge, Epic™, Galaxy S™7, S6, S5, S4, S3, S2, & S, Galaxy Note™ 4, 3, & 2, and Moment

Apple®

Requirements:

- Phones or tablets with iOS 5.1.1 or newer
- A cellular data plan
- The current eKEY application downloaded to the Apple phone or tablet

Supra eKEY Fob or Adapter is not needed for iBox BTLE (Bluetooth 4.0) if the Apple products are:

- iPhone models 4s or newer
- Retina iPad model or newer
- iPad Mini

Use a Supra eKEY Fob:

For iBox BT LE devices with older Apple products or when opening an iBox BT (Bluetooth 2.0) device.

- iPhone models 4 and older
- iPad 2 models and older
- iBox BT device

Some Example Devices:

Open an iBox BT LE without using a Supra Fob:

iPhone®	iPhone 7, 7 Plus, 6s, 6, 6 Plus, SE, 5s, 5c, 5, and 4s
iPad®	iPad Mini, iPad Pro, 4 th Generation and 3 rd Gen.

BlackBerry®

Requirements:

- Phones or tablets with OS 5 or newer, except BlackBerry 10
- A cellular data plan
- The current eKEY application downloaded to the BlackBerry phone



Supra eKEY Fob

Some Example Devices:

BlackBerry	8800 series Bold™ Touch Curve™ Pearl™/Pearl Flip Storm™ Torch™ Tour™
-------------------	--

Contact Support at 1-877-699-6787 if you have a question about a specific phone or tablet.

**Compatible eKEY App Devices
List
Click Here**

www.supraekey.com

